Syphon Dump Valve

For use with emergency tank showers, the purpose of the syphon dump valve is to automatically replenish a proportion of the water in the tank at regular intervals. This process prevents the build up of bacteria in the tank and ensure the water is kept clean. The water dump frequency can be easily adjusted to suit site requirements.



Specifications

MATERIALS OF CONSTRUCTION	
VALVE	Plastic
SERVICES	
FLUSHING VOLUME	13.5 L
THREAD	1" BSPP
WEIGHTS and DIMENSIONS	
DIMENSIONS -LENGTH	233mm



www.hughes-safety.com